



CHEST TUBES CLOGGING - A FAMILIAR PROBLEM





PLEURAFLOW ACT MAINTAINS CHEST TUBE PATENCY





Find a partner & locate training materials




4

SYSTEM & COMPONENTS



THE PLEURAFLOW ACTIVE CLEARANCE SYSTEM






PleuraFlow System Overview




STANDARD CHEST TUBE PLACEMENT METHODS

Pleural or mediastinal placement is performed according to standard methods





PLEURAFLOW SYSTEM IN USE



 \approx

AVAILABLE IN VARIOUS SIZES & CONFIGURATIONS



As with selection and placement of any chest tube, care must be taken to ensure that the tube drainage eyelets remain contained within the chest cavity for the duration of application.



10

IMPORTANT TO KNOW!





The PleuraFlow System is ONLY compatible with the PleuraFlow Chest Tube (included in package)





The PleuraFlow Guide Tube and Chest Tube cannot be mismatched





The system connects to any drainage canister






The system is NOT MRI compatible



11

SYSTEM FUNCTION & USE





ASSEMBLE THE SYSTEM






Once the Chest Tube has been placed, cut the Chest Tube.

ALWAYS cut at the **cut line**. Never shorter.





Next, connect Chest Tube to proximal end of Guide Tube.

Ensure straight & flush connection.



Slow and steady motion

PLEURAFLON

FLONGLIDE


JER ON THE STEET OF THE

Move Clearance Wire & Loop into Parked Position.

Ensure a slow and steady motion.



18



ACTUATE THE DEVICE





Magnetic Safety Release - Decoupling



Magnetic Safety Release - Decoupling



MAGNETIC SAFETY RELEASE - DECOUPLING



MAGNETIC SAFETY RELEASE - DECOUPLING COMMON CAUSES IN THE OR

- Incision site too small constricting the chest tube
- 2 Suture is too tight constricting the chest tube
- Kinks or bends obstructing Clearance Wire movement
- Actuating too rapidly (most common cause)







Testing an Actuation in the OR



OR RECOMMENDED ACTUATION SCHEDULE

Phase	Recommended Timing
Prior to chest closure	Confirm initial advancement into Parked Position
Prior to ICU transfer once PleuraFlow System is connected to drainage canister and suction	Every 15 minutes
	Once prior to leaving the OR

 $[\]ensuremath{^{*}}$ This should be repeated as necessary to keep the tube patent and free of any occlusions.



Magnet Strength Button



BEFORE LEAVING THE OPERATING ROOM

	Actuate one last time
--	-----------------------

- Leave Shuttle Guide in Parked Position
- Alert ICU about PleuraFlow placement and last actuation time
- Communicate any Magnetic Safety Release Decoupling issues



ADDITIONAL CONSIDERATIONS



Contraindicated for patients with a history of intolerance to implantable silicone materials



Do not place the Shuttle Guide within 15 cm (6 inches) of an implanted pulse generator such as pacemakers or implanted defibrillators



The PleuraFlow System is **NOT** MRI Compatible



The PleuraFlow System is Latex Free



31

PLEURAFLOW SYSTEM - OR KEY TAKEAWAYS

- 1
- **%**--

Always cut on the Cut Line

2



Confirm advancement of Clearance Wire & Loop and actuate every 15 minutes

3



Leave in Parked Position prior to leaving OR





Inform the ICU about PleuraFlow placement



